

Operating Instructions for Advertising Pillar



Dirk Joachimsmeier

Tel: 02 91 90 24 691

Fax: 02 91 90 24 799

Mobil: 01 70 33 00 300

dirk.joachimsmeier@airlebniswelt.com

airlebniswelt GbR

Schützenstraße 50 • 59872 Meschede

Tel: 02 91 90 24 691 • Fax: 02 91 90 24 799

info@airlebniswelt.com

www.airlebniswelt.com

Geschäftsführer:

Dominik Stracke • Dirk Joachimsmeier

Steuernr: 334 5701 0624 • FA Meschede

Sparkasse Meschede

Kto: 466 49

BLZ 464 510 12

Please read these instructions carefully before setting up the display.
These instructions are part of the sales contract between the customer and airlebniswelt GbR.

Description of function:

This inflatable is a display with a height of 2 to 4m, which is set up with one fan. Due to the continuous pressure of the fan, the display keeps in shape. The fan must be running all time.


Place of installation:

The area of operation needs to be a horizontal place of 1m². Remove this area from dirt and light items, which can be absorbed by the fan and destroy the fan. These items can also change the color of the inflatable. To avoid damages and soiling of the inflatable, make sure that in the radius (Hmax) of the Skydancer are no power supply lines, pylons, chimneys, guttering, traffic signs, as well as oily, sharp edged or dirty objects.

Installation:

Do a final visual check before you fasten the Velcro of the advertising fabric to the bottom plate.

Connect the Advertising Pillar to 22V power. The inside lighting (if ordered) switches on and the fan starts blowing. Lift up the fabric to support the fan until the Pillar is fully blown up. In between 1-2 minutes the Advertising Pillar is set up.



Deflation of the Pillar:

If a lighting system is on the bottom plate, make sure that the fabric is not lying on the warm lights after deflation. This can cause damages on the fabric.

Conditions of service:

Ideal results are in non-windy weather. The usage of the Advertising Pillar is allowed if it is barely windy and lightly raining. The usage of the inflatable is not allowed if the conditions are rough (wind and rain).